

TONNEAU FITTING INSTRUCTION

Falcon XD-XE-XF-XG-XH

1979 – 1998

Part number: 104

Package includes

1 X Tonneau cover

1 X Tonneau lock

1 x Fitting Instructions

2 x Rivets (300803)

17 x Anti Abrasive Discs

1. CARING FOR YOUR TONNEAU

To Fit Anti-Abrasive Discs: Firstly clean the area behind each bunji head with a clean rag and methylated sprits. Then attach the anti-abrasive discs centrally behind each bunji head.

Apply bee's wax or Dri-lube to stitching a few times a year, as this will maintain the tonneau's waterproofing ability and prevent the stitching from degrading. Use a mild detergent and soft scrubbing brush to clean tonneau.

Never drive without tonneau support bars in place as flapping can cause a delaminating effect on the material.

"Tonneau is not designed to be used as a load restraint"

2. TONNO LOCK

The Tonno Lock is now a standard feature included with all Tuff Tonneaus. The Tonno Lock is situated at the front of the tonneau cover, so as not to impede the accessibility of the Tuff Tonneau.

Fitting the lock is simple and only requires a small attachment on the inside edge of the tub behind the cab.

Together with a padlock, it provides you with an

extremely effective theft deterrent. The Tonno Lock is

designed to suit all utes and prevent thieves stealing your Tuff Tonneau, so you can continue to rely on the Tuff Tonneaus' name to give you what you want in a tonneau cover.



2.1 BASIC TOOL REQUIRED

Rivet gun, Drill, Torch, and Marking Pencil/Pen.

You will need to buy a small Padlock- make sure the padlock will go through the hole on the Tonno lock.

2.2 TONNO LOCK CONTENTS

- 2 X 4MM Aluminium rivets
- 1 x Tonno Lock bracket

2.3 FITTING TONNO LOCK

1. Fit the front of the Tonneau to the front of the ute tub placing the LTD clips (Fitted on the Tonneau Cover) on to the LTD posts already fitted on the body of the vehicle (Behind rear windscreen).
2. Fit your tonneau cover support bar/s into position.
3. Drape cover over support bars.
4. Fit Bunji Loops to Body Hooks, starting at the rear then fitting the sides bunjis.
5. To fit Tonneau lock Bracket refer step 2.
6. Your Tuff Tonneaus Tonneau Cover is now fitted.

3. WARRANTY AND FEEDBACK

Please register your warranty details online at:

QR Code:



Website Link:

<http://www.tto.com.au/en-au/warranty.html>

Please complete our 2 minute feedback section as we strive to constantly improve for our customers.

Your Tuff Tonneau is now ready for work.