

# Tonneau Cover Fitting Instructions

## VE / VF Commodore

2007 - 2017

**Part Number: 213**

### Package includes

1 X Tonneau cover	1 x Lock Bracket
1 x Commodore Extrusion	2 x Rivets
1 x Fitting Instructions	2 x Black Support Bar (2 Lengths)

## 1. TONNEAU COVER FITTING

**NOTE** Read entire instructions prior to start.

The plastic strip at the front of the tonneau cover is designed to slide into the middle track of the commodore extrusion.

If you are experiencing problems fitting the tonneau cover, adjust the length by sliding the plastic strip into the front or rear track of the commodore extrusion

All parts supplied with the cover must be used for it to fit correctly. Do not use genuine fitting kit.

### 1.1 BASIC TOOLS REQUIRED

Drill, 4mm Drill Bit, Rivet Gun, Marking Pencil / Pen

## 1.2 TONNEAU COVER INSTALLATION PROCEDURE

1. Fit the two Support Bars into the designated holes in the tub liner. The longer bar is the front bar, the shorter one is for the back.
2. To fit the front extrusion, have the front plastic inserted into the centre groove of the extrusion.
3. Slide the aluminium with the end caps vertically up into the recessed notches behind the cab.
4. Once the extrusion is all the way up on both sides, rotate it 90 degrees so the plastic sewn into the cover is on the top.
5. The extrusion then slides back towards the tailgate to lock it into position.

### Using Internal Elastic Shock Cord:

6. The plastic clips on the internal shock cord can be hooked into the aluminium extrusions so that the cover can still be secured with larger loads in the tub.

## 2. CARING FOR YOUR TONNEAU

Apply bee's wax or Dri-lube to stitching a few times a year, as this will maintain the tonneau's waterproofing ability and prevent the stitching from degrading. Use a mild detergent and soft scrubbing brush to clean tonneau.

**Never drive without tonneau support bars in place as flapping can cause a delaminating effect on the material.**

## 3. TONNO LOCK

The Tonno Lock is now a standard feature included with all Tuff Tonneaus. The Tonno Lock is situated at the front of the tonneau cover, so as not to impede the accessibility of the Tuff Tonneau.

Fitting the lock is simple and only requires a small attachment on the inside edge of the tub behind the cab. Together with a padlock, it provides you with an extremely effective theft deterrent. The Tonno Lock is designed to suit all utes and prevent thieves stealing your Tuff Tonneau, so you can continue to rely on the Tuff Tonneaus' name to give you what you want in a tonneau cover.

### 3.1 BASIC TOOL REQUIRED

Rivet gun, Drill, Torch, and Marking Pencil/Pen.

You will need to buy a small Padlock- make sure the padlock will go through the hole on the Tonno lock.

### 3.2 TONNO LOCK CONTENTS

- 2 X 4MM Aluminium rivets

- 1 x Tonno Lock bracket

### 3.3 FITTING TONNO LOCK

1. Attach the black lock bracket to the bracket on the tonneau with your padlock, and fit the tarp.
2. Getting under the tarp with a torch, place the lock bracket against the body and mark holes with a pen.
3. Remove tonneau and drill the marks with a 4 mm drill bit, place the lock bracket in position and rivet.

## 4. WARRANTY AND FEEDBACK

**Please register your warranty details online at:**

**QR Code:**



**Website Link:**

<https://www.tto.com.au/en-au/warranty.html>

**Please complete our 2 minute feedback section as we strive to constantly improve for our customers.**

**Your Tuff Tonneau is ready for work.**