

# TONNEAU INSTALLATION INSTRUCTION

## Ford Falcon FG June 2008 - Current

**Part number: 10659**

### Package includes

<input type="checkbox"/> 1 x Tonneau Cover	<input type="checkbox"/> 1x Lock Bracket
<input type="checkbox"/> 1 x Fitting Instructions	<input type="checkbox"/> 4 x Bar Brackets
<input type="checkbox"/> 2 x Bar Cover	<input type="checkbox"/> 30 x 4mm Rivets
<input type="checkbox"/> 2 x Long Support Bars	<input type="checkbox"/> 20 x Buttons
	<input type="checkbox"/> 20 x Anti Abrasive Discs

# 1. TONNEAU COVER FITTING

**NOTE** Read entire instructions prior to start.

## 1.1 BASIC TOOL REQUIRED

Drill, 4mm Drill Bit, Rivet Gun, Marking Pencil / Pen, Straight Edge or String Line

## 1.2 TONNEAU COVER INSTALLATION PROCEDURE

1. To fit the bar brackets, measure 640mm and 1240mm back from the outside front edge of the tub and place them as shown in **Figure 1**. Drill and rivet using two large rivets for each Bar Bracket. Install the support bar according to the supplied instructions.



**Figure 1:**

Bar Brackets placed  
640mm & 1240mm  
from front of tub.

2. Fit the front of the Tonneau Cover to the front of the Ute tub placing the three Plastic Retainers (Fitted on the Tonneau Cover) on to the Metal Lip on the Steel Body (the lip 30mm down from the top of the tub) between the cabin and the Ute Body. (Behind rear windscreen).
3. To fit buttons to the tailgate measure 80mm down from the bottom edge of the lip of the tub (**Shown in Figure 2**) at both sides of the tailgate and using a non-permanent marker mark these positions. Using a straight edge or string line, draw a line between these positions, so that the line extends across the width of the tailgate.



**Figure 2:**

Measure and mark 80mm down from bottom edge of lip.

4. Drape the cover over the support bars and centre it. Working from the centre two bunjis out mark the location of each bunji on the line drawn in step 3. As you mark the location of each button drill and rivet buttons along the line, attaching each bunji to the buttons as you go. **See Figure 3.**



**Figure 3:**

Working from centre out mark, drill and rivet each button and attach bunjis as you go.

5. To fit buttons to the sides of the tub start by drawing a line 80mm down from the bottom edge of the lip of the tub, just like on the tailgate in Step 3. But this time from the front to the back of the tub.
6. Locate the rear Passenger Side bunji on the line, then mark, drill and rivet a button in place. Attach bunji and repeat for the rear Drivers Side bunji.
7. Continue attaching buttons along the line in line with each bunji, working from the rear to the front and alternating from Passenger Side to Drivers Side. **See Figure 4.**



**Figure 4:**

Working from the rear to front of each side, drill and rivet each button and attach bunjis, alternating sides as you go.

8. To Fit Anti-Abrasive Discs: Firstly clean the area behind each bunji head with a clean rag and methyated sprits. Then attach the anti-abrasive discs centrally behind each bunji head.

## 2. TONNO LOCK

The Tonno Lock is now a standard feature included with all Tuff Tonneaus. The Tonno Lock is situated at the front of the tonneau cover, so as not to impede the accessibility of the Tuff Tonneau.

Fitting the lock is simple and only requires a small attachment on the inside edge of the tub behind the cab. Together with a padlock, it provides you with an extremely effective theft deterrent. The Tonno Lock is designed to suit

all utes and prevent thieves stealing your Tuff Tonneau, so you can continue to rely on the Tuff Tonneaus' name to give you what you want in a tonneau cover.



### 2.1 BASIC TOOL REQUIRED

Rivet gun, Drill, Torch, and Marking Pencil/Pen.

You will need to buy a small Padlock- make sure the padlock will go through the hole on the Tonno lock.

### 2.2 TONNO LOCK CONTENTS

- 2 X 4MM Aluminium rivets
- 1 x Tonno Lock bracket

### 2.3 FITTING TONNO LOCK

1. Attach the black lock bracket to the bracket on the tonneau with your padlock, and fit the tarp.
2. Getting under the tarp with a torch, place the lock bracket against the body and mark holes with a pen.

3. Remove tonneau and drill the marks with a 4 mm drill bit, place the lock bracket in position and rivet.

### 3. MULTI-FIT SUPPORT BAR

The Tuff Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Subaru Brumbys to Cab Chassis aluminium trays.

Part No: 300517



#### 3.1 BASIC TOOL REQUIRED

Drill, 4mm drill bit

#### 3.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece
- 1 x Tonneau bar sheath

#### 3.3 FITTING MULTI-FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws**. Then place the tonneau sheath over the bar to stop the bar wearing against the tonneau. Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.

**Warning if you do not fit the tonneau sheath over the bar, the tonneau cover will quickly wear through which is not covered by warranty.**

## 4. WARRANTY AND FEEDBACK

Please register your warranty details online at:

QR Code:



Website Link:

<http://www.tto.com.au/en-au/warranty.html>

Please complete our 2 minute feedback section as we strive to constantly improve for our customers.