

Nissan Navara Dual Cab 4WD STX / ST D40 / 550

With Factory Sports Bars

2006 to June 2015

Part number: 332

Package includes

| | |
|--|---|
| <input type="checkbox"/> 1 X Tonneau Cover | <input type="checkbox"/> 2 x Bar Brackets |
| <input type="checkbox"/> 1 x Tonneau Support Bar | <input type="checkbox"/> 28 x Rivets |
| <input type="checkbox"/> 3 x Aluminium Rope Track-498mm long ea. | <input type="checkbox"/> 1 x Lock Bracket |
| <input type="checkbox"/> 1 x Support Bar Sheath | <input type="checkbox"/> 16 x Rope Buttons |
| <input type="checkbox"/> 1 x Fitting Instructions | <input type="checkbox"/> 4 x Dowel |
| | <input type="checkbox"/> 16 x Anti Abrasive Discs |

1. TONNEAU COVER FITTING

NOTE Read entire instructions prior to start.

1.1 BASIC TOOL REQUIRED

Drill, 4mm Drill Bit, Rivet Gun, Marking Pencil / Pen

1.2 TONNEAU COVER INSTALLATION PROCEDURE

1. Using two pieces of dowel, join the 3 aluminium rope tracks together. Place the other 2 pieces of dowel in the ends of the now joined rope track.
2. Rest the aluminium rope track on the side rails, and push forward. **Figure 1** to the vertical face of the tub.
3. Using a 4 mm drill bit, drill 6 holes 50mm from the end of each of the aluminium rope tracks into the front of tub.
4. Once all the holes have been drilled, remove the dowelling pieces. Squeeze silicon sealant along the back of the rope tracks and pop rivet into place.
5. Slide the front of the tonneau cover through the aluminium rope track section.
6. To fit the bar brackets, measure 740mm back from the inside front edge at the top of the tub and place them as shown in **Figure 2**. (15mm down from top edge of tub) Drill and rivet using two large rivets for each Bar Bracket. Install the support bar according to the supplied instructions.
7. Neatly lay tonneau out over support bar and tub in the installed position. Fasten all collars around sports bar legs with the press studs.
8. To fit the rope buttons to tub, use the panel crease in both the tailgate and side panels as a reference line, **See Figure 3**. Starting with the **tailgate**, line up vertically each button to each ring grip and drill and rivet each button to the crease, so that the top edge of the button is in line with the top edge of the crease. For the **side panels**, follow the same procedure as with the tailgate, drill and rivet buttons alternating from one side to other side of the tub.
9. To Fit Anti-Abrasive Discs: Firstly clean the area behind each bunji head with a clean rag and methylated sprits. Then attach the anti-abrasive discs centrally behind each bunji head.




Figure 1: Placement of aluminium rope track. Ensure channel is above the tub's top edge.




Figure 2: Placement of bar bracket




Figure 3: Placement of rope button is along panel crease and vertically inline with each ring grip.

2. TONNO LOCK

The Tonno Lock is now a standard feature included with all Tuff Tonneaus. The Tonno Lock is situated at the front of the tonneau cover, so as not to impede the accessibility of the Tuff Tonneau.

Fitting the lock is simple and only requires a small attachment on the inside edge of the tub behind the cab. Together with a padlock, it provides you with an extremely effective theft deterrent. The Tonno Lock is designed to suit

all utes and prevent thieves stealing your Tuff Tonneau, so you can continue to rely on the Tuff Tonneaus' name to give you what you want in a tonneau cover.



2.1 BASIC TOOL REQUIRED

Rivet gun, Drill, Torch, and Marking Pencil/Pen.

You will need to buy a small Padlock- make sure the padlock will go through the hole on the Tonno lock.

2.2 TONNO LOCK CONTENTS

- 2 X 4MM Aluminium rivets
- 1 x Tonno Lock bracket

2.3 FITTING TONNO LOCK

1. Attach the black lock bracket to the bracket on the tonneau with your padlock, and fit the tarp.
2. Getting under the tarp with a torch, place the lock bracket against the body and mark holes with a pen.
3. Remove tonneau and drill the marks with a 4 mm drill bit, place the lock bracket in position and rivet.

3. MULTI-FIT SUPPORT BAR

The Tuff Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Subaru Brumbys to Cab Chassis aluminium trays.



3.1 BASIC TOOL REQUIRED

Drill, 4mm drill bit

3.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece
- 1 x Tonneau bar sheath

3.3 FITTING MULTI-FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws**. Then place the tonneau sheath over the bar to stop the bar wearing against the tonneau. Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.

Warning if you do not fit the tonneau sheath over the bar, the tonneau cover will quickly wear through which is not covered by warranty.

4. WARRANTY AND FEEDBACK

Please register your warranty details online at:

QR Code:



Website Link:

<http://www.tto.com.au/en-au/warranty.html>

Please complete our 2 minute feedback section as we strive to constantly improve for our customers.

Your Tuff Tonneau is now ready for work.